

No connection to chimneyenvironmental protection

- environmental protect
- no exhaust emissions
- human and animal friendly



Ideal for use with a gas boiler

the boiler operating counter switches the gas boiler On when the energy consumption limit set on the Bosman LED panel is reached **STOP**

 CO_2

Electric heating boilers Elterm <u>PV ready</u>

YEARS ELTERM

Sergeant

10.0000

12.2022



680



70 55

↑ ¾″Ext.

580

70 70

↑ ¾″Ext.

¾″Ext.♥



Protection selection	4 kW	4 kW	6 kW	6 kW	9 kW	12 kW	15 kW	18 kW	24 kW
	1 phase	2 phases	1 phase	3 phases	3 phase				
Fuses (A)	1 x 20	2 x 10	1 x 32	3 x 10	3 x 16	3 x 20	3 x 25	3 x 32	3 x 40
Power cord (mm²)	3 x 4	5 x 2.5	3 x 4	5 x 2.5	5 x 2.5	5 x 4	5 x 4	5 x 6	5 x 10

* The exact cross-section of the power cord is selected by the electrician on the basis of an analysis of the local conditions. ** protection table for boilers above 24 kW (from 30 kW to 1.5 MW) available at www.elterm.pl



ELTERM M.M. Kaszuba Sp. J. 86-200 Chełmno ul. Przemysłowa 5 www.elterm.pl